








ASSEMBLY INSTRUCTIONS

BYRON DARK TIMBER OUTDOOR SET WHITE


Please read instructions carefully. Remove all wrapping material and packing from the carton. See hardware and furniture parts list for guidance. Be sure you have all parts before you start to assemble the product. Place all furniture parts on a clean surface, such as carpet or rug to prevent the item from being scratched.



A x 16  M6x30 mm	B x 8  M8x60 mm	C x 8  Ø8xØ18 mm	D x 1  4 mm
---	--	---	--





⑧ x 4
⑦ x 1
⑥ x 2
⑤ x 2
④ x 2
③ x 2
② x 2
① x 2




1


x2



2


x2






3

x2





4

x2



5

x2



6

